



Massage Wave Mode Indicator

Raise/Lower Head

Hi-Low Up/Down

Raise/lower entire bed.

Massage On/Off

+/- Head Massage Intensity

Raise/Lower Foot

Massage Wave Mode Selector

+/- Foot Massage Intensity

Set/Light*/Lock

- 1. Set - Memory position set. Press and hold 5 sec to program a new memory position.
- 2. Light - Underbed Lighting on/off
- 3. Flat- Press and release to return all motors to flat position.

3 Programmable Memory Buttons

Press and hold "Set" 5 sec to program a new position, then select M1, M2, or M3 to save that position. Press and release to go to a programmed position.

WIRED & WIRELESS Hand Controls

USE YOUR SMARTPHONE AS A REMOTE

Simply download the Okin Smart Remote App and pair your phone with your bed.

Note: If you did not select optional add-ons with your bed, the buttons will be present on the hand control but will not function.